

HOW TO CLEAN THE DERWENT SUPERPOINT SHARPENER




- Twist the handle Anti Clockwise. This will loosen the handle.



- Pull out the handle towards you. You will soon see that there is a helix blade attached to the handle



- Clear of any debris with a brush. You also want to make sure there are no obstructions stuck in the area circled in the image above.



- Also want to make sure you can see the 'hole' down the middle of the blade. If you cannot see anything then there is something stuck in the blade.